Evaporative Cooler: Model EV2076EC

INSTRUCTION MANUAL – IMPORTANT INSTRUCTIONS RETAIN FOR FUTURE USE - READ FULLY BEFORE USE

Pictures or product specifications may vary slightly from those indicated due to ongoing product improvement.

Safety Instructions

Carefully read this manual in full before using this electric evaporative cooler. Ensure that you know how the appliance functions and how to operate it. Maintain the appliance in accordance with the instructions to ensure that it functions properly. Keep this manual with the appliance. If the appliance is to be used by a third party, this instruction manual must be supplied with it. The safety instructions do not by themselves eliminate any danger completely and proper accident prevention measures must always be used. No liability can be accepted for any damage caused by non -compliance with these instructions or any other improper use or mishandling.

Package Contents

I x Instruction Manual 1 x Evaporative Cooler 1 x Remote Control

CAUTION. Confirm all parts before disposing of packaging. Safely dispose of all plastic bags and other packaging components. They may be potentially dangerous to children.

Usage

This cooler may be used as a standard fan or with water – ice added to aid in the cooling process. This appliance is not an air conditioner. It operates by standard fan operation or by blowing air through a damp filter to further reduces the air temperature. It may be used with either water or ice under COOL mode.

Assembly and Installation

This appliance requires no specific assembly or maintenance.

Install appliance on a level surface only away from direct sunlight or heat source. This appliance must be connected to an earthed mains outlet.

Remote Control

The remote control requires 2 AAA size batteries (not supplied). Remove the rear battery cover and fit according to the instructions located inside the battery compartment of the remote control. **Note.** Always remove batteries when not in use. Always use batteries of a similar type and make, do not mix battery brands.

Operation – Normal

Fan Control

Connect to the mains supply and switch on. Select ON/OFF button and press to commence. Appliance will commence normal "Fan Only" function with the last speed selected. Indicators will light.

Fan Speed Control

To increase fan speed simply press the SPEED button to move between Low – MED - HIGH. Indicators will light.

Fan Swing Control

To commence oscillation mode when ON press the SWING button, to stop press SWING button again. Indicator will light.

Fan Delay Control

To operate for a pre-programmed period before switching to OFF mode automatically follow the following steps. Press ON pad to start and set the fan speed and mode function. Press the TIMER pad until the desired delay OFF time is shown. Each press of the delay pad will increase the delay time in 30 minute steps up to a maximum of 4 hours.

Random Control

In RANDOM mode the fan speed will vary to simulate the effect of natural breezes. Press ON pad to start the fan and set the fan speed desired. Press FAN MODE button until the RANDOM indicator lamp is on. The fan will automatically switch between HIGH – MED – LOW settings at short intervals to simulate random breeze function.

Sleep Control

In SLEEP mode the fan can be programmed to diminish in speed over a period and then also to turn OFF automatically when used in conjunction with TIMER function or until switched off. For example in SLEEP mode if the fan set to High speed, the fan will operate in HIGH RANDOM mode for 30 minutes then switch to MED RANDOM mode for 30 minutes before switching to LOW RANDOM mode for 30 minutes. If the delay TIMER has been set the fan will operate in LOW RANDOM mode until automatically switching off at the timer end.

Operation – Cool

Open the water tank fill door (located on front of appliance) and fill with water to the MAX water limit. **WARNING!** Do not over fill. Do not move appliance when full of water.
Press the ON button to start fan operation, select fan speed desired and press COOL button to operate in COOL mode. The fan will operate at 2-6 degrees cooler than in normal mode.

Operation – Cool Ice

Instead of adding water you can add ice to the ice tray (located under the top lid). The ice will melt and travel down through the cooler to the water tank, helping to lower the cooling temperature. **WARNING!** If using water tank and Ice combination ensure that the water tank is not more than half full to ensure that the water bucket does not overflow.

Operation – Remote Control

The remote controller operates all functions of the air cooler. Simply point the remote control at the appliance and press the ON/OFF button to start appliance operation. Choose desired settings by pressing the COOL – SWING – TIMER – MODE TYPE – SPEED buttons.

Warning! Do not move when full of water or over fill.
Warning! Ensure that the appliance is switched OFF from the mains supply before filling with water.
Warning! Avoid contact with moving parts. Do not insert objects or body parts into the safety grill when operating.
Warning! Do not cover or place near curtains or other heat source such as direct sunlight or any heater.
Warning! This appliance should not be placed in the immediate vicinity of water, such as bathtub, wash bowls, swimming pool or other area were splashing may occur.

IMPORTANT SAFETY INFORMATION

When using electric appliances always observe safety regulations where applicable to reduce the risk of fire, electric shock and personal injury including the following.
Always check that the power supply corresponds to the voltage on the rating plate.

Supply

This electric appliance must be connected to a suitable 230-240 V ~ 50Hz power supply. If using an extension cord, ensure that the extension cord is of a suitable 10-amp power rating. Fully unwind the supply cord when in use as a coiled cord may overheat. Do not abuse or damage the power cord. If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard. **Warning! Always unplug from the mains supply when not in use.**

Children

Caution. Keep out of reach of children. This appliance is not intended for use by young children or infirm persons. Young children must be supervised by a responsible person to ensure that they can operate the appliance safely. Young children should be supervised to ensure that they do not play with the appliance

Use and environment

Do not use outdoors. Do not leave in direct sunlight as this may damage the plastic. This appliance is for household use only, not commercial or industrial use. The power socket must be readily accessible so that the appliance can be unplugged in an emergency.

Damaged or dropped

Always inspect your appliance before use. Do not use if it has been damaged, dropped, left outdoors or dropped in water. Return it to an authorised service dealer for examination and repair.

Water

Do not immerse in water or other liquids or use near washbasins or sinks or wet environments. Ensure that the appliance does not get wet (water splashes etc.) and do not use it with wet hands.

CLEANING

Before cleaning.

When not in use or before cleaning always disconnect from the mains supply. **Warning!** Ensure that the appliance is switched OFF from the mains supply before removing any guard or filter or filling with water.

Cleaning

Carefully wipe the outer surface with a damp cloth, dry with a dry towel. Do not use harsh abrasives, solvents, chemical cleaners, petrol or similar to clean this appliance as these may damage the plastics.

Filter

Remove the rear filter regularly and clean any dust that may accumulate. Filter may be washed or cleaned with a soft brush.

Empty water

To empty water from the water tank switch the power off and remove from the power supply. Open the water outlet tap located on the rear of the water tank.

Store in a safe place

When not in use store your appliance and instruction manual in a safe and dry place.

evantair

Warranty

This product is for household use only. This product is guaranteed against faulty materials and workmanship for a period of 24 months from the date of purchase. The obligation to the purchaser under this warranty is limited to servicing the unit and replacing defective parts when the product is returned freight prepaid to the retailer. This warranty becomes void if the product has been tampered with, damaged by accident, damaged in any other way by improper use or has been purchased second hand. All production orders have quality inspections. In the unlikely event of a deficiency, please contact the retailer from whom this product was purchased.

Model No.: _____ Purchase date:_____ Product Purchased From:_____

IMPORTANT!

Please retain this warranty card along with your purchase receipt. Please do not post to the retailer or importer. If service is required, both of these documents are to be returned with the appliance to your retailer, otherwise a fee may be charged.